


Required Tools

measuring
tape



drill with
2mm bit



phillips bit or
screwdriver



pencil




knife



Included Hardware

Only relevant hardware is included with your delivery.



Inside (Top Fix)
55mm Swivel
Installation Bracket



Outside (Face Fix)
80-110mm Swivel
Installation Bracket



Outside (Face Fix)
51mm Snap-in
Installation Bracket



Track
(20x16mm)



Runner



Pinch Pleat Hook
(attached to fabric)



End Cap (open end)



End Cap (stack end)



Left Overlap Carrier



Right Overlap Carrier



Screws for Wood,
Metal or Wall Plugs



Wall Plugs for
Brick or Cement
(using a 6mm bit)

1

Installation Brackets for Track

Installing inside the window frame...

- At the top of the window frame, measure 150mm in from each side and mark with a pencil, this is the centre of the outer brackets.
- Measure 47mm back and mark where the screw will go.
- We recommend drilling pilot holes for the screws using a 2mm bit.
- Fix the brackets into position using 1 screw for each bracket.
- Ensure all brackets are aligned and perpendicular to the window opening.
- If more brackets are supplied, space them evenly between the first 2 brackets.



Installing on the ceiling...

- Ensure you have a solid mounting surface to screw the brackets into, preferably timber, brick or metal.
- Measure 150mm in from the end of where you want the track to sit and mark where the outside screws of the brackets will go.
- Place the brackets in position and mark where the screw will go.
- We recommend drilling pilot holes for the screws using a 2mm bit.
- Fix the brackets into position using 1 screw for each bracket.
- Ensure all brackets are aligned and perpendicular to the window opening.
- If more brackets have been supplied, space them evenly between the first 2 brackets.



Installing outside the window frame...

- **On the Architrave:** Measure 150mm in from each side of the top of the architrave and mark with a pencil, this is the centre of the outer brackets.
- Place brackets in position (generally flush with the top of the architrave) and mark where the screws will go.
- We recommend drilling pilot holes for the screws using a 2mm bit.
- Fix the brackets into position using 2 screws for each bracket.
- If more brackets have been supplied, space them evenly between the first 2 brackets.
- **On the Wall:** Ensure you have a solid mounting surface to screw the brackets into, preferably timber, brick or metal.
- Ensure the track sits evenly each side of the window opening.
- We recommend using a spirit level to align brackets.
- Measure 150mm in from each end of where you want the track to sit and mark with a pencil, this is the centre of the outer brackets.
- Place brackets in position and mark where the screws will go.
- We recommend drilling pilot holes for the screws using a 2mm bit.
- Fix the brackets into position using 2 screws for each bracket.
- If more brackets have been supplied, space them evenly between the first 2 brackets.

Installation continued...

2 Install Track

Left or right stack (one curtain):

- Count the number of hooks on your curtain and minus one, this is the number of runners required.
- Remove track end cap (stack end) and remove the extra runners not required from the track.
- Replace end cap (stack end) onto track and tighten screw.
- **Swivel Brackets:** Place track in position and turn the swivel handle to lock track into brackets.
- **Snap-in Brackets:** Place track in position and push the back of the track up, to snap into place. Alternatively, the screws can be removed from the plastic snap-in and manually screwed in place.

Centre opening (two curtains):

- Count the number of hooks on both curtains and minus two, this is the number of runners required.
- Remove a track end cap and remove the extra runners not required from the track.
- Replace end cap onto track and tighten screw.
- **Swivel Brackets:** Place track in position and turn the swivel handle to lock track into brackets.
- **Snap-in Brackets:** Place track in position and push the back of the track up, to snap into place. Alternatively, the screws can be removed from the plastic snap-in and manually screwed in place.

Centre opening with overlap (two curtains):

- Count the number of hooks on left curtain and minus two, this is the number of runners required.
- Remove left track end cap and remove the extra runners not required from the track.
- Replace end cap onto track and tighten screw.
- Count the number of hooks on right curtain and minus two, this is the number of runners required.
- Remove right track end cap and remove the extra runners not required from the track.
- Replace end cap onto track and tighten screw.
- **Swivel Brackets:** Place track in position and turn the swivel handle to lock track into brackets.
- **Snap-in Brackets:** Place track in position and push the back of the track up, to snap into place. Alternatively, the screws can be removed from the plastic snap-in and manually screwed in place.

3 Install Curtain

- Hold curtain in front of the end of the track that the curtain will stack too.
- Attach the first hook to the end cap, then attach the rest of the hooks to the runners.
- If two curtains, do the same for the other curtain starting from the other end of the track.
- To adjust the height of the curtain, simply adjust each hook as required.
- Your curtain is now ready for use.

Great Job... Enjoy your new Veneta Curtains!

Operating your
Curtain

- The Veneta Curtains are hand drawn and slide by moving the fabric to the desired position.