

Required Tools

measuring
tape



drill with
2mm bit



phillips bit or
screwdriver



pencil



knife



Included Hardware

The hardware can be found in the small plastic bag included with your blind.



Installation Bracket
(inside window frame)



Installation Bracket
(outside window frame)



Child Safety
Guide



Screws for Wood,
Metal or Wall
Anchors



Wall Anchors for
Brick or Cement

Feedback?

Please write a review on our website letting us know your experience with Veneta Blinds

www.venetablinds.com.au

1 Installation Brackets

Installing inside the window frame...

- At top of window frame, measure 90mm in from each end and 40mm back from the front of the window frame, and mark the screw position for the small round hole on bracket.
- Place brackets in position and mark where the other screws will go.
- We recommend drilling pilot holes for the screws using a 2mm bit.
- Fix the brackets into position using 2 screws for each bracket.
- If more brackets are supplied, space them evenly between the first two brackets.



Installing outside the window frame...

- Measure 90mm in from top left and top right of where the blind will sit (normally edge of architrave) and mark the position of the centre of the brackets.
- Place brackets in position and mark where the other screws will go.
- We recommend using a spirit level to align brackets if not installing on the architrave.
- We recommend drilling pilot holes for the screws using a 2mm bit.
- Fix the brackets into position using 2 screws for each bracket.
- If more brackets are supplied, space them evenly between the first two brackets.

2 Install Blind

- Note the position of the bracket in the photo to the right...
- Position the second lip on top of the headrail into the front lip of bracket.
- Tilt the back of the blind up and apply firm pressure at the back of the blind, to click the blind into place.



Installation continued...

3 Child Safety Guide

- Position the Child Safety Guide on the wall where the chain is at a slight tension but still allowing for smooth operation, and mark where the screw will go.
- We recommend drilling pilot holes for the screws using a 2mm bit.
- Fix the Child Safety Guide into position using 1 screw.



Great Job... Enjoy your new Veneta Blinds!



WARNING

ALL WINDOW COVERINGS WITH CORD OR CHAIN

To avoid creating a possible strangulation hazard for children, the corded internal window covering must be installed in such a way that a loose cord cannot form a loop 220mm or longer at a height of less than 1600mm above floor level.

- A cord/chain guide may be installed lower than 1600mm above floor level if the cord/chain is sufficiently secured or tensioned to prevent a loop 220mm or longer from being formed.
- If a cord/chain guide is installed lower than 1600mm above floor level it must be designed to prevent a child from being able to remove the cord.
- If a cleat is used to secure the cord, it must be installed at least 1600mm above floor level because a child is capable of unwinding a cord from a cleat. For more information, please visit our website at www.venetablinds.com.au/child-safety.

Operating your Blind

- To operate your new Zebra blind, simply pull the chain down at the front to raise the blind or pull the chain down at the back to lower the blind.

Maintaining your Blind

1 Dusting

- Dust can be removed using a feather duster or vacuum with brush attachment on low suction.

2 Spot Cleaning

- Use a warm damp cloth or a mild detergent for tougher stains.
- Dab the affected area, but do not rub the fabric. Finish with just a warm damp cloth.
- Allow the fabric to dry in the lowered position.

Need HELP?

Customer Service

1300 836 382